Product	Version	Theme	Environment	Date	Department	Person	Language
SEE Electrical	V3R6	Printing	Windows XP	04/12/2006	Quality	Technical	EN
Expert						Support	
				bject:			
				EET IN A PDF F	ILE		
			Possidi	es causes:			
			Our prop	osed solution:			
The PDF file generated by Se	ee XP is not in vectorial	format, but in Bitmap for					
Therefore this PDF file has a	greater size that the o	one of a standard PDF file	<u>e.</u>				
To generate a PDF file, click t	he command "File/Print	/Standard Screen Shot".					
Select the file type and click							
T+ := ====: - = += ===+++====	energy DNE file of w	-11					
It is possible to protect the g The protection parameters ar							
Security:							
No Protection							
Occument B	Encrypted with Password	Protection					
Owner	Password: ××××××						
Confirm	Password: xxxxxx		_				
	-						
🔽 User Rights	<b>_</b>						
User	Password: xxxxxx						
Confirm	Password: xxxxxx						
User Has Bights I	to View PDF File and: 🕟	Edit 🗖 Copy					
Cool Hao Highlor		Print Annotate					
PDF [Portable Document For		inner in the second sec	e display colours				
	marj mala pagoa, mooolo	Nort 102411100 pinolo, 00					
		ОК	Cancel				
		00					
Owner Password"							
his password must contain 6 o	characters at least.						
his option allows generating a	PDF file which the use	r can <b>only view</b> This PDF	file cannot neither be priv	nted nor modified			
		,,					

A password is requested for the PDF file to be generated. On the other hand, no password will be requested when you open this file.

## "User Password"

This password must contain 6 characters at least.

After having defined the owner password, the user can define the user password.

This password allows generating a PDF file by authorizing or interdicting its modification, printing, copying or adding comments to it.

Upon opening of the PDF file, you must enter the owner password. One must not communicate to others his user password.