EN

The title of the dialogue box shows that you are modifying a symbol of the environment:

• <u>To update a symbol of the environment:</u>

After having saved your symbol, you must update it in the file.

- Open a sheet
- Click on the command "File/Update According to the Environment"
- Select Symbols (or Illustrations) in the "Process" tab

🎇 Update Project		
Process Application Domain		
Elements to Update		Execute
	All	Close
	None	
Symbols		
Illustrations		

- Click on "Execute"

The symbol (or the illustration) will be updated in the file.

The modified symbol is therefore available in the symbols library or explorer in order to be inserted in the sheet.

- On the other hand, if this symbol was already inserted in a sheet, it won't be updated.

To update the symbols inserted in the sheets, click on "Tools/Update of Symbols or Illustrations Inserted in the Sheet".

• Modify and update a symbol (or an illustration) of the project

- Right-click on the symbol that will be modified

	Сору
	Paste
	Cut
	Move
	Delete
Ż	Change CAD Attributes
	Modify •
	Paste Tag
	Paste CAD Attributes
	Paste Specific Attributes
	Insert Equipment
	Update Connection Points
	Delete all not connected
ют	Modity Symbol Definition
	Fix As Default
- 6	Status
25	GO CO

- Click on "Modify Symbol Definition"
- The symbol (or the illustration) is displayed in the editor

The title of the dialogue box shows that you are modifying a symbol of the project:

RE - Symbol - [QA9P3/Q06 - SYMBOL LIBRARY FROM PROJECT <EXAMPLE>]

• To update a symbol of the file

After having saved your symbol, it is automatically updated in the file.

The modified symbol is therefore available in the symbols library or explorer in order to be inserted in the sheet.

- On the other hand, if this symbol was already inserted in a sheet, it won't be updated.

To update the symbols inserted in the sheets, click on the command " Tools/Update of Symbols or Illustrations Inserted in the Sheet".