Product	Version	Theme	Environment	Date	Department	Person	Language		
SEE Electrical PLM	V4R×	Connective Device Manage	r Windows		After Sales	Technical Support	EN		
			Subject:	:					
Installing custom settings for Device and Connective Device									
Managers									
Description:									
This document describes how to install custom settings files for Device and Connective Device managers. Those xml files are used to customize the dialogue for the creation of new devices, allowing user to enter elements of the device tags, and let application calculate the final tag, avoiding so errors in the naming conventions.									
	Our proposed solution:								
For SEE Connective Device Manager The xml setting file must be installed by default under the directory: "C:\Program Files (x86)\IGE+XAO\SEE Electrical PLM - Connective Device Manager V4R5\SEE_Soft\ENV\XML\CreationPropertyCardSetting\" (adapt the path if the application is not installed in its default directory, or for versions other than V4R5)									
Name of the file must be "IGE-XAO PC <edbid> Tagging Methods V<x>.xml" Where:</x></edbid>									
- X is the version - EDBID is the pi	ot the file, f rogram name	ixed for a given SEE Ele on which you are working	ctrical PLM ve	rsion					
To check your current program name, run SEE Electrical PLM ${ m I}$ – Administration Tool The Program Name is displayed in the window that appears:									

SEE Electrical PLM ® - Administra	tion Tool - DB 1			
File Help File Help File Help PLM General Settings Cieneral Difference Differ	Application Server Information Application Server Host WKFRCTP110302 Application Server Version 4.50.06.01	Application Server Name SEE ELECTRICAL HARNESS PLM HUB 4.50 (4.50.6.1) Program Name DB 1		
୍କି Part Number ady		CAP NUM SCRL		

If program name is "DB 1", for V4R6A of SEE Electrical PLM, the file must be named:

IGE-XAO PC DB 1 Tagging Methods V7.01.xml

Several of such file can be installed, for different programs.

From SEE Connective Device Manager version V4R5 patch C and later, those parameters are activated automatically at the start of the application.

For SEE Device Manager

The xml setting file must be installed by default under the directory: "C:\Program Files (x86)\IGE+XAO\SEE Electrical PLM - Device Manager V4R5\SEE_Soft\ENV\XML\CreationPropertyCardSetting\" (adapt the path if the application is not installed in its default directory, or for versions other than V4R5)

Name of the file is the same as in case of SEE Connective Device Manager, see above.